



Výsuvný trojkoš WIRELI Style s koši na dvířka s tlumením L/P Pull out basket with door baskets WIRELI Style with soft close L/P

		A 1 Pc	B 1 Pc	C 3 Pcs	D 3 Pcs	E 1 Pc	F 1 Set	G 1 Pc	H 1 Set	I 1 Set	J 1 Pcs	K 1 Pcs	L 3 Pcs	M 4 Pcs	N 16 Pcs			
		O 2 Pcs	P 2 Pcs	Q 1 Set	R 1 Set	S 2 Pcs	T 4 Pcs	U 4 Pcs	V 2 Pcs									
1		2																
3		4																
5		6																
7		8																
9		10																
11		12																

W 600
W1 Min564
450 Min414

450-600
Min 750
Min 520

155
64
64
316
4-Ø2
538
Min 520

450-600
Min 750

a 600
h 256
450 181
e 254.5
179.5

E
L600 L450
30 30 30
6-Ø2
496
177
87
a
h

4-Ø2
622
34
32
10
O
R

F
f
170
a
a 600
f 226 450 151

2
1
3
4
T
H
1⇒2⇒3⇒4

V
S
B
R
U
S
V
R
U

I
T

N
O
2
P
M
3
5
4
O
1
Q

J
L
K

D
C

